

One Time Assembly Instructions

Lacrosse



Snap the pipes together, insert both carriage bolts and then tighten the nyloc nuts, with the wrench included. **Hint:** Assemble the inside pipes first. The green monofilament nylon cord runs straight up each joint / pipe.

